



# 2COP Interface Circuit Board







**Connections to the AD1000EN-1R/  
AD1000 EN3-R Main Unit**

Plug the cable into the side of main unit.

**Connections to the AD1000EN-4R  
Main Unit**  
(Cut the BT Plug & Strip the wires)

Red Wire - Terminal "CAR/S"  
Blue Wire - Speech Synth Terminal Block  
Green Wire - Speech Synth Terminal Block  
White Wire - Terminal "CAR/S"



White Cable for Pictogram and/or Inductive Loop

White Cable for Pictogram and/or Inductive Loop

White Cable for Pictogram and/or Inductive Loop

To 12v Supply from the Autodialler Main Unit

To the "A" terminal and the "+" of the Autodialler Board

Pictogram/Inductive Loop connection for both speaker needs to be connected in Parallel